

**Dirt Killer
Orifice Size Chart**

How to choose the right nozzle orifice size

- To use the chart below, find your PSI in the TOP row. Scan down to your closest GPM.
- Choose the exact or higher GPM> Scan right to the ORIFICE SIZE column.
- Buy an nozzle with an ORIFICE that size or LARGER. Never buy a nozzle with a smaller orifice. It will break your machine.

		PSI													
Orifice Size	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	
2	1.2	1.4	1.6	1.7	1.9	2	2.1	2.2	2.3	2.4	2.5	2.6	2.7	2.8	
2.5	1.6	1.8	2	2.2	2.3	2.5	2.7	2.8	2.9	3.1	3.2	3.3	3.4	3.5	
3	1.8	2.1	2.4	2.6	2.8	3	3.2	3.4	3.5	3.7	3.8	4	4.1	4.2	
3.5	2.2	2.5	2.8	3.1	3.3	3.5	3.7	3.9	4.1	4.3	4.5	4.6	4.8	4.9	
4	2.5	2.8	3.2	3.5	3.7	4	4.2	4.5	4.7	4.9	5.1	5.3	5.5	5.7	
4.5	2.8	3.2	3.6	3.9	4.2	4.5	4.8	5	5.3	5.5	5.7	6	6.2	6.4	
5	3.1	3.5	4	4.3	4.7	5	5.3	5.6	5.9	6.1	6.4	6.6	6.8	7.1	
5.5	3.4	3.9	4.3	4.8	5.1	5.5	5.8	6.2	6.4	6.7	7	7.3	7.5	7.8	
6	3.7	4.2	4.7	5.2	5.6	6	6.4	6.7	7	7.3	7.6	7.9	8.2	8.5	
6.5	4	4.6	5.1	5.6	6.1	6.5	6.9	7.3	7.6	8	8.3	8.6	8.9	9.2	
7	4.3	4.9	5.5	6.1	6.5	7	7.4	7.8	8.2	8.6	8.9	9.3	9.6	9.9	
7.5	4.6	5.3	5.9	6.5	7	7.5	8	8.4	8.8	9.2	9.6	9.9	10.3	10.6	
8	4.9	5.7	6.3	6.9	7.5	8	8.5	8.9	9.4	9.8	10.2	10.6	11	11.3	
8.5	5.21	6.01	6.72	7.36	7.95	8.5	9.02	9.5	-	-	-	-	-	-	
9	5.5	6.4	7.1	7.8	8.4	9	9.6	10.1	10.6	11	11.5	11.9	12.3	12.7	
9.5	5.82	6.72	7.51	8.23	8.89	9.5	10.08	10.62	-	-	-	-	-	-	
10	6.1	7.1	7.9	8.7	9.4	10	10.6	11.2	11.7	12.2	12.7	13.2	13.7	14.1	
11	6.74	7.78	8.7	9.53	10.29	11	11.67	12.3	-	-	-	-	-	-	
12	7.3	8.5	9.5	10.4	11.2	12	12.7	13.4	14.1	14.7	15.3	15.9	16.4	17	